

Wheelchair Lifts

Questions	Yes	No	Dimension (As-Built)	Modifications/ Notes
1. Is the lift operable on the day of the survey?				
2. If a wheelchair lift is used to change levels, is there a 60-inch by 60-inch landing in front of the lift door? (If the lift was installed prior to 1/1/14, is there maneuvering space large enough for a person using a 30-inch by 48-inch wheelchair to enter, operate the lift, and exit?)				
3. If the lift entry door has a front approach, is the door clear space at least 32 inches wide?				
4. If the lift entry door has a side approach, is the door clear space at least 42 inches wide?				
5. Does the lift allow a wheelchair user unassisted entry, operation, and exit?				
6. Are the controls for the lift no higher than 48 inches above the floor? (If the lift was installed prior to 1/1/14, controls for a side approach may be up to 54 inches above the floor.)				
7. Are the wheelchair lift controls usable with one hand without tight grasping, pinching, or twisting of the wrist?				
8. Does the lift have standby power in case of an emergency that will allow the lift to operate five up and down trips?				